

vtech[®]
Baby

User's Manual

Little Friendlies 2-in-1 Baby Gym



© 2013 VTech
Printed in China
91-002852-007 

VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years




To learn more about this and other VTech® products, visit www.vtechuk.com

INTRODUCTION


Thank you for purchasing the **Little Friendlies 2-in-1 Baby Gym** learning toy!

Your little one will love to play in the **Little Friendlies 2-in-1 Baby Gym** by **VTech®**! Your baby will develop motor and sensory skills as they reach out to grasp fun dangling animals and shapes. An electronic sun panel provides fun stimulation including sing-along songs for language development. Play peek-a-boo with the baby-safe mirror that introduces self discovery.



INCLUDED IN THIS PACKAGE

- One instruction manual
- 1 play mat




- 1 cuddly cow toy




- 1 bear



- 4 arch pieces



- 1 electronic sun panel




- 1 sheep




- 1 frog



- 1 baby-safe mirror




- 2 straps with buckles



- 1 bird



- 6 activity links



Included In This Package

WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.


NOTE:

Please keep this instruction manual as it contains important information.

INSTRUCTIONS

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit. Use a screwdriver to loosen the screw.
3. Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure the battery cover.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.

- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in Battery Directive (2006/66/EC).

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Help protect the environment by disposing of your product or batteries responsibly.

For more information, please visit:

www.recycle-more.co.uk

www.recyclenow.com



WARNING:

For your child's safety when playing on the play mat unsupervised please remove the attachment and straps and store them in a safe place.


ASSEMBLY INSTRUCTIONS

With the VTech® Little Friendlies 2-in-1 Baby Gym safety comes first. To ensure your child's safety, adult assembly is required.

1. Insert one of the arch pieces into the round slot in the blue cloud hub. You will hear a “click” sound when the arch is inserted correctly.



2. Repeat the above process with the remaining arch piece. Once the arches are assembled, they can't be disassembled.
3. Lay the play mat on a flat surface with the animal character side facing up. Insert the end of each of the arches into the slots on each of the four corners of the playmat.




4. Attach the dangling animal characters and the mirror to the arches by threading the activity links through the loops on the arches.



5. Insert the recessed slot on the back of the electronic sun panel in to the round attachment on the cloud hub. Thread the strap through the parallel holes on the back of the sun panel. Thread the strap up through one side of the rectangular buckle and down through the other side of the buckle. Pull on the strap to tighten the buckle. Repeat the above process with the second strap and buckle.







Make sure the straps of the electronic sun panel are attached securely to the arches before placing baby under the arches. The sun panel also can be attached to a cot rail.






PRODUCT FEATURES

1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit **ON**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **LOW VOLUME** () or the **HIGH VOLUME** () position. To turn the unit **OFF**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **OFF** () position.



2. MODE SELECTOR SWITCH

Slide the **MODE SELECTOR SWITCH** to the **Animal Mode** (), **Colours & Shapes Mode** () or **Music Mode** () position.



3. AUTOMATIC SHUT OFF


To preserve battery life, the **Little Friendlies 2-in-1 Baby Gym** will automatically power-down after approximately 30 seconds without input. The unit can be turned on again by pressing any button or by moving the dangling pieces.

ACTIVITIES


1. Slide the **ON/OFF/VOLUME CONTROL SWITCH** to turn the unit on. You will hear a welcoming phrase, playful sounds and a sing-along song related the selected mode. The light will flash with the sounds.




2. Press the **animal buttons** to hear animal names, sounds and songs in the **Animal Mode**, colours, sounds and short tunes in the **Colours & Shapes Mode** and random melodies in the **Music Mode**. The light will flash with the sounds.



3. Pull the **dangling shapes** to hear sounds and short tunes in the **Animal Mode**, colours, shapes, short tunes and sounds in the **Colours & Shapes Mode** and random melodies in the **Music Mode**. The light will flash with the sounds.



4. Slide the **butterfly** to hear a variety of playful sounds and short tunes. The light will flash with the sounds.



5. Activate the motion sensor to hear playful sounds, phrases, short tunes and songs. The light will flash with the sounds.



MELODY LIST

1. Mary Had a Little Lamb
2. Baa, Baa, Black Sheep
3. Old MacDonald Had a Farm
4. Bingo
5. The Old Grey Mare
6. Farmer in the Dell
7. One, Two, Buckle My Shoe
8. Three Little Kittens
9. Daisy Bell
10. Three Blind Mice
11. Little Miss Muffet
12. Aiken Drum
13. Mary, Mary, Quite Contrary
14. Yankee Doodle
15. She'll Be Coming 'Round the Mountain
16. And the Green Grass Grew All Around
17. Ring Around the Rosy
18. Chicken Reel
19. This Old Man
20. Pop! Goes the Weasel
21. Happy Farmer
22. Way Down Upon Swanee River
23. Rock-a-bye Baby
24. On Top of Old Smokey

Sing-Along Song Lyrics

Sing-Along Song 1

Wave your arms and kick your feet.
The animals are ready, they want to play!

Sing-Along Song 2

Colours, colours all around,
How many colours can be found?

Sing-Along Song 3

Twinkle, twinkle, big bright sun,
Showing off your golden light!

Sing-Along Song 4

Baa, baa, bleats the little white sheep!

Sing-Along Song 5

Moo-moo-moo, the cow sings for you.
Moo-moo-moo-moo-moo.

Sing-Along Song 6

Cluck, cluck, cluckity cluck,
Chicken sings a happy song!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. The play mat is machine washable. Please remove all play pieces from the playmat and follow the care instructions on the tag.
3. Keep the unit out of direct sunlight and away from any direct heat source.
4. Remove the batteries when the unit will not be in use for an extended period of time.
5. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK) and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **VTech®** products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department on 01235 546810 (from UK) or +44 1235 546810 (outside UK), with any problems and/or suggestions that you might have. A service representative will be happy to help you.

**CLASS 1
LED PRODUCT**



PRODUCT WARRANTY



Thank you for choosing this quality product from VTech. We hope it will bring many hours of entertainment, imaginative play and learning.

1. The product detailed above is covered by a one year warranty from the date of purchase, against any defects in materials or workmanship.
2. The product may be returned to the place of purchase. Alternatively the product can be returned to VTech Electronics Europe plc (see address below), with proof of purchase, without proof of purchase no replacement will be provided.
3. VTech Electronics Europe plc will examine the product and if it is found to be defective due to faulty materials or workmanship, will replace the product at their discretion.
4. If the product covered by this warranty is damaged due to misuse, modification or unauthorised repair, or because of faulty batteries, battery discharge or incorrect electrical connections, then this warranty becomes void.
5. This warranty is personal to the original purchaser and is not transferable.
6. Breakages to the LCD screen are not covered by the warranty.
7. Returns to VTech Electronics Europe plc should include a cheque or postal order for £1.50 towards the cost of return postage and packaging.
8. Products returned to VTech Electronics Europe plc, should be addressed as follows and packed carefully to avoid damage in transit (Please do not include batteries or adaptor).
Please include details of the fault together with your name and address.

VTech Electronics Europe plc, c/o Tablogix Limited, 200 Milton Park, Abingdon, Oxon OX14 4TA

THIS WARRANTY IS OFFERED AS AN EXTRA BENEFIT AND DOES NOT AFFECT CONSUMERS' STATUTORY RIGHTS.

This warranty is valid for the UK and Eire only. For products purchased outside the UK and Eire, please contact your local distributor or place of purchase.

