

vtech[®]
baby

Instruction Manual

Soothing Sounds Firefly



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school


4-10 years



To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **Soothing Sounds Firefly**. Ideal for playtime and relaxing, with lights and sounds for giggles and snuggles. Light up little ones day and night!



Nature Sounds
Button

Heart
Button

Music
Button

Off/Low/High
Volume Switch



Timer Switch

INCLUDED IN THE PACKAGE

- Soothing Sounds Firefly
- Quick Start Guide

WARNING

All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.


WARNING:

Keep this soft toy out of the sleeping environment for babies under twelve months to avoid suffocation risk.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Locate the battery cover on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries are recommended for maximum performance.)
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.

Keep batteries out of reach of children.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.

Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:

www.vtech.co.uk/recycle

www.vtech.com.au/sustainability

* Visit www.recyclenow.com to see a list of collection points near you.

PRODUCT FEATURES

1. Off/Low/High Volume Switch

To turn the unit **On**, slide the **Off/Low/High Volume Switch** to the Low volume (🔊) or High volume (🔊🔊) position. You will hear an opening tune, phrases, songs and melodies. To turn the unit **Off**, slide the **Off/Low/High Volume Switch** to the **Off** ● position.



2. Timer Switch

Slide the **Timer Switch** to select **15**, **30** or **45** minutes of music or sounds. Once the chosen time has ended, the unit will automatically power down.



3. Automatic Shut-Off

To preserve battery life, the **Soothing Sounds Firefly** will automatically power down after the selected time. The unit can be turned on again by pressing any button.


NOTE

This product is in try-me mode in the packaging. To activate normal play, turn the unit **Off**, then turn the unit back **On**. If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES

1. Heart Button

Press the **Heart Button** to hear sing-along songs, phrases and soothing melodies. The light will flash with the sound. Press the **Heart Button** when a song, sound or melody is playing to stop the audio response.



2. Nature Sounds Button

Press the **Nature Sounds Button** to hear an assortment of nature sounds. The light will flash with the sound



3. Music Button

Press the **Music Button** to hear relaxing melodies. The light will flash with the sound.



MELODIES

1. Debussy - Clair de Lune
2. Pachelbel - Canon in D
3. All Through the Night
4. Mozart - Piano Sonata No 10
5. Shannon - Irish Lullaby
6. Strauss - The Blue Danube Waltz
7. Tchaikovsky - Sleeping Beauty
8. Vivaldi - Le quattro stagioni - Spring
9. Au Clair de la Lune
10. Glow Worm

11. Hickory Dickory Dock
12. Hot Cross Buns
13. Humpty Dumpty
14. Rock A Bye Baby
15. Incy Wincy Spider
16. Lavender's Blue
17. Little Bo-Peep
18. Little Miss Muffet
19. Looby Loo
20. Lullaby and Goodnight
21. Mulberry Bush
22. Pat-A-Cake
23. Ring Around A Rosy
24. Row, Row, Row Your Boat
25. Skip to My Lou
26. Three Little Kittens
27. Twinkle Twinkle Little Star
28. White Coral Bells
29. Winkum, Winkum
30. Teddy Bears' Picnic
31. Roses Are Red
32. Ride A Cock Horse to Banbury Cross
33. Oats, Peas, Beans, and Barley Grow

SONG LYRICS

Song 1

I'm a little firefly,
When my heart is full of love,
I like to glow.

Song 2

Time to relax and wind down,
Let's go on a calming journey.

Song 3

I'm a firefly, I like to shine.

I play all day and relax at night.

We're best friends, I am here for you.

I love you and you love me too.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to excess moisture.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit sit for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play with again.
5. If the product still does not work, install a brand new set of batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED – CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

