

My Everyday Gadgets



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech Baby

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school

4-10 years



To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Thank you for purchasing the **VTech® My Everyday Gadgets!** Don't forget your phone and keys when you're on-the-go! Flip open the phone for engaging lights, app content, songs and melodies! Close it to explore the animal friend poppers! Explore the keys for silly sounds and textured popper keys with a bear tether too! There's so much to discover!

Six Double-Sided
Soft Poppers



On/Off Volume Switch

Six Light Up Buttons

Baby's Car Keys



INCLUDED IN THE PACKAGE

- My Everyday Gadgets
- Quick Start Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

WARNING


Adult supervision is required

- * When playing with the poppers, ensure they are kept an appropriate distance away from the eyes and face of you or another person.
- * Do not put, or attempt to launch anything on the poppers.

NOTE

This toy phone has reduced volume to adhere to safety regulations for close-to-the-ear toys.

Removing the packaging locks:



- ① Turn the packaging locks anticlockwise several times.
- ② Pull out and discard the packaging locks.


GETTING STARTED

WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.

Battery Removal and Installation

1. Make sure the unit is turned OFF.
2. Locate the battery cover located on the back of the unit, use a screwdriver to loosen the screw, and then open the battery cover.
3. If a used battery is present, remove it from the unit by pulling up on one end of the battery.
4. Install 1 new AAA (AM-4/LR03) battery following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.



IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheeled bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.



The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.

The solid bar indicates that the product was placed on the market after 13th August, 2005.

Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:




www.vtech.co.uk/recycle


www.vtech.com.au/sustainability

* Visit www.recyclenow.com to see a list of collection points near you.

PRODUCT FEATURES

1. On/Off Volume Switch

To turn the unit **On**, slide the **On/Off Volume Switch** to the **Low Volume** () or the **High Volume** () position. You will hear a song, phrases and sounds. To turn the unit **Off**, slide the **On/Off Volume Switch** to the **Off** () position.



2. Automatic Shut-Off

To preserve battery life, the **My Everyday Gadgets** will automatically power down after approximately 30 seconds without input. The unit can be woken up again by flipping open or closing the phone, or by pressing any buttons.

NOTE

If the unit powers down during play, please install a brand new battery.

ACTIVITIES


1. Flipping Phone

Flip the phone open to enter App Mode.
Close the phone to enter Animal Mode.
The light will flash with the sounds.



2. App Mode

When in App Mode, press the Light Up App Buttons for fun app content, songs, melodies and to learn colours. The light will flash with the sounds.



3. Animal Mode

When in Animal Mode, press the Squishy Animal Poppers to learn animal names, hear animal sounds and call the animal friends. The light will flash with the sounds.




4. Soft Poppers

Press the double-sided squishy soft poppers for press & pop play.



5. Baby's Car Keys

Press the car key buttons for silly sounds. Feel the different textures on the keys to stimulate the senses. Baby can use the bear teether to soothe sore gums.



MELODIES

1. Polly Put the Kettle On
2. Grieg - Peer Gynt Suite No.1, Op.46 - 1. Morning Mood
3. Hickory Dickory Dock
4. Boccherini - String Quintet in E major, Op. 11, No. 5, G. 275: III. Minuetto
5. Toyland
6. Puccini - Nessun Dorma
7. Row, Row, Row Your Boat
8. Rossini - Il Barbiere di Siviglia: "Cavatina di Figaro"
9. MacNamara's Band
10. Verdi - Rigoletto, Act III - La donna è mobile

SONG LYRICS

Song 1

Red, orange, green and blue,
Red, orange, green and blue,
Red, orange, green and blue,
And yellow and purple too!

Song 2

Can you hear the phone ringing?
The phone ringing? The phone ringing?
Can you hear the phone ringing?
I wonder who is calling!?

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the battery if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the battery.
3. Let the unit stand for a few minutes, then replace the battery.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a brand new battery.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

