

vtech[®]

Instruction Manual

Sort & Discover Activity Wagon



VTech understands that a child's needs and abilities change as they grow and with that in mind we develop our toys to teach and entertain at just the right level...

vtech *Baby*

Toys that will stimulate their interest in different textures, sounds and colours

I am...

...responding to colours, sounds and textures

...understanding cause and effect

...learning to touch, reach, grasp, sit-up, crawl and toddle

Birth-36 months



Pre-School

Interactive toys to develop their imagination and encourage language development

I want...

...to get ready for school by starting to learn the alphabet and counting

...my learning to be as fun, easy and exciting as can be

...to show my creativity with drawing and music so my whole brain develops

3-6 years



Electronic Learning Computers

Cool, aspirational and inspiring computers for curriculum related learning

I need...

...challenging activities that can keep pace with my growing mind

...intelligent technology that adapts to my level of learning

...National Curriculum based content to support what I'm learning at school


4-10 years



To learn more about this and other VTech® products, visit www.vtech.co.uk

INTRODUCTION

Load up and get ready to roll with the **Sort & Discover Activity Wagon**, featuring four sides packed with exciting activities that will spark imagination and curiosity. The wagon is perfectly sized for toddlers to pull around their favourite toys.



INCLUDED IN THE PACKAGE

- Electronic Panel
- Side Panel
- Bottom Panel
- 2 End Panels
- Handle
- 4 Wheels
- 4 Shape Sorting Blocks
- Label Sheet
- 9 Screws
- Quick Start Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

INSTRUCTIONS

WARNING:

Adult assembly required for battery installation.

Keep batteries out of reach of children.




CAUTION:

Adult assembly required. This product contains small parts. For your child's safety, do not let your child play with the toy until it is completely assembled.

BATTERY REMOVAL AND INSTALLATION

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the back of the **Electronic Panel**. Use a screwdriver to loosen the screw and then open the battery cover.
3. If used batteries are present, remove these batteries from the unit by pulling up on one end of each battery.
4. Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended).
5. Replace the battery cover and tighten the screw to secure.



IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

Disposal of batteries and product



The crossed-out wheellie bin symbols on products and batteries, or on their respective packaging, indicates they must not be disposed of in domestic waste as they contain substances that can be damaging to the environment and human health.

The chemical symbols Hg, Cd or Pb, where marked, indicate that the battery contains more than the specified value of mercury (Hg), cadmium (Cd) or lead (Pb) set out in the Batteries and Accumulators Regulation.



The solid bar indicates that the product was placed on the market after 13th August, 2005.



Please dispose of your product and batteries responsibly.

In the UK, give this toy a second life by disposing of it at a small electricals collection point* so all of its materials can be recycled.

Learn more at:





www.vtech.co.uk/recycle

www.vtech.com.au/sustainability

* Visit www.recyclenow.com to see a list of collection points near you.

LABEL APPLICATION


Please securely stick the labels to the activity panels as indicated below:



ASSEMBLY INSTRUCTIONS

With the **Sort & Discover Activity Wagon** safety comes first. To ensure your child's safety, adult assembly is required. For your child's safety, do not let your child play with the toy until it is fully assembled.


1. Please make sure the **VTech®** logo side of the **Bottom Panel** is facing up. Connect the **Electronic Panel** and the **Side Panel** to the **Bottom Panel** first. Next, connect the two **End Panels** to the **Bottom Panel**. You will hear the pieces click together when inserted correctly. Use the 9 **Screws** to secure the panels together.




Bottom Panel





Electronic Panel




Side Panel



2 End Panels



2. Attach the 4 **Wheels** to the **End Panels**. Push the **Wheels** onto the supports until you hear the **Wheels** click twice and are flush with the supports.



Note:




Attaching the wheels requires firm pressure. We recommend placing the wagon on it's side on the floor, then pushing down on the wheels.

3. Connect the **Handle** to the **End Panels**. Push the **Handle** down until you hear the **Handle** click into place.



PRODUCT FEATURES

1. **On/Off/Volume Switch**

To turn the unit **On**, slide the **On/Off/Volume Switch** to the **Low Volume**  or the **High Volume**  position. You will hear a song and phrases.
To turn the unit **Off**, slide the **On/Off/Volume Switch** to the **Off**  position.



2. Automatic Shut-Off

To preserve battery life, the **Sort & Discover Activity Wagon** will automatically shut down after approximately 30 seconds without input. The unit can be turned on again by interacting with any of the features on the **Electronic Panel**.

NOTE

If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES

1. Number Buttons

Press the **Number Buttons** to hear numbers, colours, shapes and melodies. The light will flash with the sound.



2. Roller

Spin the **Roller** to hear fun sounds and short tunes. When a short tune is playing, roll the **Roller** again quickly to speed up the short tune. The light will flash with the sound.



3. Twisting Lion

Twist the **Twisting Lion** to hear cute phrases, sounds, songs and music. The light will flash with the sound.




4. Flip Page

Turn the **Flip Page** to hear the animals identified, short tunes and playful sounds. The light will flash with the sound.



5. Peek-a-boo Doors

Slide the **Peek-a-boo Doors** to learn about the animals, hear sounds and short tunes. The light will flash with the sound.




6. Motion Sensor

Push or pull the wagon to activate the **Motion Sensor** and hear a phrase, fun sounds and short tunes.

7. Shape Sorting

For added fun, push the **Shape Sorting Blocks** into the matching slots on either end of the wagon.



MELODIES

1. Alphabet Song
2. A-Tisket, A-Tasket
3. Bingo
4. The Entertainer
5. Girls and Boys Come Out to Play
6. Hey Diddle Diddle
7. Hickory, Dickory, Dock
8. Hot Cross Buns
9. Humpty Dumpty
10. Little Bo-Peep
11. Mary Had a Little Lamb
12. Old MacDonald
13. On Top of Old Smokey
14. Row, Row, Row Your Boat
15. Skip to My Lou

16. Teddy Bears' Picnic
17. Toyland
18. The Wheels on the Bus

SONG LYRICS

Song 1

We're going on an adventure,
Can you see any animals?
Spin or slide, play peek-a-boo,
There's so many animals to see.

Song 2

Fill up the wagon, I'm ready to play.
I wonder what we'll find on our journey today.
Push me or pull me,
What will we see?

Song 3

1, 2, 3, 4, 5!
My wheels roll round and round.
5, 4, 3, 2, 1!
There's so much to see and explore.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

If the problem persists, please contact our Consumer Services Department and a service representative will be happy to help you.

CONSUMER SERVICES

Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department with any problems and/or suggestions that you might have. A service representative will be happy to help you.

UK Customers:

Phone: 0330 678 0149 (from UK) or +44 330 678 0149 (outside UK)

Website: www.vtech.co.uk/support

Australian Customers:

Phone: 1800 862 155

Website: support.vtech.com.au

NZ Customers:

Phone: 0800 400 785

Website: support.vtech.com.au

PRODUCT WARRANTY/ CONSUMER GUARANTEES

UK Customers:

Read our complete warranty policy online at vtech.co.uk/warranty.

Australian Customers:

VTECH ELECTRONICS (AUSTRALIA) PTY LIMITED –
CONSUMER GUARANTEES

Under the Australian Consumer Law, a number of consumer guarantees apply to goods and services supplied by VTech Electronics (Australia) Pty Limited. Please refer to vtech.com.au/consumerguarantees for further information.

**Visit our website for more
information about our products,
downloads, resources and more.**

www.vtech.co.uk
www.vtech.com.au

